


### 72ZCVCSS

### Safety Screen Installation / Removal

Screen Dimensions: 19-1/8" x 73-5/8"



To remove Safety Screen, **WAIT UNTIL FIREPLACE IS COMPLETELY COOL.** Push up at the top center of the Screen Frame, and pull away from the fireplace.

# AN <u>UNVENTED CHASE REQUIRES NON-COMBUSTIBLE COVERING</u> (I.E., CONCRETE BOARD) OVER THE FRONT FACE OF THE APPLIANCE.

#### A <u>Vented Chase can have a Combustible covering</u> (i.e., drywall) over the front face of the appliance.

**Notice:** Granite, tile, or other facing materials are not covered by the fireplace warranty. Natural stone, tile, and other facing materials may crack or discolor (i.e. yellowing of lighter colored materials).

# NOTE: these issues can be avoided if the Chase is Vented.

Televisions are not covered by fireplace warranty.

Notice: DurockR Brand Cement Board: The manufacturer recommends CGC SheetrockR Brand DurabondR 90 Setting- Type Drywall Compound rather than a ready-mix product for finishing.

When finishing the wall around the fireplace, it is critical that the wall covering be fastened properly. It is acceptable to pre-drill holes and use self-tapping screws which may be used to fasten a backer for tile, marble, etc. Screws being installed through non-combustible board should be self-tapping type with a maximum length of 2 inches.

# Do not drill or install longer screws (over 2") as this may damage internal components.

• We recommend that CONCRETE BOARD (noncombustible material) be tied in to the entire perimeter of the fireplace for durability.

**Finishing Recommendations** (Obtained from professional construction contractors and finishers):

- Frame unit with metal studs (minimum 20 gauge). Wooden studs may be used, but may cause drywall screws to pop or pull due to wood studs drying out.
- Minimum of 1/2" CONCRETE BOARD cement board (this **non-combustible** panel is ULC listed as a wall shield/floor protector) and fasten to the entire perimeter framing.
- Use fiberglass (mesh) tape for all joints in area of the fireplace.
- Use Yellow joint mud (contains high amounts of glue) two coats, finishing with one coat of green topping mud, sand and prep for painting.
- If not using a surround, a metal "L" Trim may be used to finish perimeter of CONCRETE BOARD.
- OTHER NOTES:

-A full single sheet of non-combustible board (no joints) above the unit is recommended if possible.

-It is preferred to attach the non-combustible board to **framing only** and not directly to the unit to allow for expansion and contraction during normal operation.

-Lighter colored painted surfaces may discolor due to heat exposure.

### ZCVRB72

This section is intended for qualified installers only. Before beginning, make note of where the gas and electrical accesses are located on the unit. This will streamline the construction process. Furthermore, familiarize yourself with the venting and clearance requirements (see Venting section) for this appliance. Failure to comply with those requirements can seriously compromise the safety and operation of the fireplace.

#### Specifications

- Cold climate installation recommendation: When installing this fireplace against non-insulated exterior wall or chase, it is recommended that the outer walls be insulated to conform to applicable insulation codes. Drywall & vapor barrier must be installed over insulation to prevent contact of insulation and unit.
- 2. Choose fireplace location and frame in accordance with the fireplace framing dimensions specified (view diagrams).
- 3. Drywall or other combustible material can extend up to the Drywall Stops located on the sides of the unit, and up to the bottom and top.

4. A Hearth is not required for this unit.

#### Vertical Venting in Cold Climates

In cold climate conditions where temperatures go below -10 degrees Celsius or 14 degrees Fahrenheit, we recommend that the chase be insulated and where the vent pipe enters into the attic space that the pipe be wrapped with an insulated Mylar sleeve. This will increase the temperature of the vent and help the appliance to vent properly in cold weather conditions.


It is also important in vertical vented direct vent appliances that the appliance be operated daily during the winter months as this will help stop the termination from freezing up. We recommend using a thermostat set at room temperature to allow the unit to cycle.

For IPI models it may be necessary to set the appliance to Standing Pilot mode to maintain heat in the cavity. The purpose of this procedure is to prevent cold air from penetrating the chimney and then onto the living space. Therefore, when the internal temperature is slightly elevated the fireplace is able to freely exhaust its combustion and hence making it easier to startup.

Certified for installation in a bedroom or bedsitting room. In Canada must be installed with listed millivolt thermostat. In USA see local codes.


#### **Stand-off Locations**

Make note of where the stand-off locations are. These stand-offs are provided as indicators to illustrate the boundaries for framing. Therefore, no framing material is permitted to extend beyond these stand-offs.





# ZCVRB72


## Nailing Tab Guide



# 72ZRB-TLK ZCVRB72 Tile Lip Kit







## ZCVRB72 – Unvented Chase VS Vented Chase- Choose Your Installation

#### Look at the following chart before you begin the installation.

	Lowest Enclosure	Wall Surface Temperature above front of fireplace	TV above Fireplace with Recessed Installation option	Mantel Height (From Bottom of Unit)	Heat can be directed to second room
UNVENTED CHASE	79"	Moderately Hot	Not Recommended	40-1/2"	No
VENTED CHASE	79"	40% Cooler than unvented chase	Yes (Recommended)	28"	Yes


#### FRAMED AS

#### **UNVENTED CHASE:**

This is a traditional fireplace installation where the fireplace is built into an unvented chase.

- <u>Non-Combustible Materials Must be used</u>
  <u>on face of fireplace</u>
- Wall surface temperature will be moderately hot
- TV above Fireplace is not recommended
- Mantel height is higher

Fireplace will be installed with Ventilation Plates in place (as shipped).




#### FRAMED AS

#### VENTED CHASE:

The fireplace is installed into a vented chase. There are many different styles of vented chase. See pages in manual for installation details and information.

- <u>Combustible Materials may be used on face of</u> <u>fireplace</u>
- Chase walls will be cool to the touch.
- A TV is allowed above the fireplace (recommended)
- Mantel height is lower

Fireplace will be installed with **Ventilation Plates Converted** (see instructions in manual).



**A CAUTION:** IF VENTILATION PLATES ARE CONVERTED, YOU **MUST** VENT THE CHASE!

## ZCVRB72 Locating Your Appliance

umm

#### LOCATION KEY:

- A. Flat on Wall
- B. Across the Corner
- C. As an Island
- D. As a Room Divider
- E. Flat on Wall Corner

See Mantel Leg Clearances Instruction for

F. Exterior Wall

the proper placement of fireplace.

ñ**n**000

#### Island installation with a top vent is possible as long as the horizontal portion of the vent system does not exceed 20


ZCVRB72


feet (6.1 m).

### Fireplace Dimensions



### LEFT SIDE







### ZCVRB72 -Mantel Clearances –Unvented Chase- Ventilation Plates in Place -As Shipped

Before installing any mantels, it is important to determine the combustibility of its material(s). There are two types of mantels to consider: Combustible and Non-Combustible Non-Combustible. Mantel Line A Combustible Mantel is one that consists of material(s) that may discolor, 45 combust, or lose its integrity in the presence of heat. These types of mantels must strictly conform to the dimensional requirements shown. Conversely, a Non-Combustible Mantel is one that is constructed with material(s) 14 that will not combust. Check your local 10 codes and regulations to determine 79' whether your mantel is Combustible or MIN Non-Combustible. 12-1/2" The advantage to Non-Combustible Noncombustible' Area Mantels is that it may extend right up to the tile lip of the fireplace. Combustible mantels must adhere to the dimensional restrictions shown. 40-1/2" Mantel Dimensions MIN 20" Combustible Objects on Non-Opening Combustible Mantel Warningare from front face or Combustible objects must not be placed on 28" Non-Combustible a Non-combustible Mantel unless the **Facing Materials** mantel meets the dimensional covering fireplace. requirements for a Combustible Mantel. Determine whether your mantel conforms · o o 🕀 to the requirements of a Combustible Mantel. Combustible Hearth is allowed below opening of appliance 19







# ZCVRB72 -Clearance to Combustibles –Unvented Chase-Ventilation Plates in Place – As Shipped


Clearance to Combustibles ZCVRB72 Unvented Chase					
Front	36" [92cm]				
Back (from Stand-offs)	0" [0cm]				
Side (from Stand-offs)	0" [0cm]				
Floor	0" [0cm]				
Minimum Ceiling Height (from bottom of fireplace)	79" [201cm]				
Top (from Stand-offs)	0" [0cm]				
Top of 90° Bend in minimum Enclosure of 79"	4" [10.2cm]				
Top of 90° Bend in Enclosure over 79"	4" [10.2cm]				
VENTING SYSTEMS					
Top of Horizontal Pipe	2" [5cm]				
Side & Bottom of Horizontal Pipe	1" [2.5cm] All Vent Systems				
Vertical Vent Pipe	1" [2.5cm] All Vent Systems				
REFER TO FACING REQUIREMENTS SECTION FOR FACING MATERIALS					

ELECTRICAL WIRES IN CHASE MUST BE PROPERLY ATTACHED TO INSIDE WALL OF CHASE. DO NOT RUN WIRES ABOVE THE APPLIANCE.

▲ **NOTE:** If using insulation in unvented chase (i.e. for outside wall), wall board / drywall is required to support all insulation.


Unvented chase must be clean and free of all debris (i.e. loose insulation, pieces of wood, etc.).


<u>▲ NOTE:</u> HEAT CANNOT BE DISCHARGED INTO THE WALLS, FLOOR, OR CEILING.



## **ZCVRB72 Facing Requirements for Non-Vented Chase** Fireplace is installed As Shipped, with Ventilation Plates in place.

ANY MATERIALS COVERING THE FACE OF THE FIREPLACE MUST BE NON-COMBUSTIBLE (I.E., BRICK, STONE, TILE, CONCRETE BOARD) AS SHOWN BELOW.





Note: Do not drive excessively long screws into the face of the unit as internal parts may be damaged.